

Artisan Cement Tile Installation Guidelines

EQUIPMENT & MATERIALS

- Thinset (light or dark to match tile color)
- Notched trowel
- Clean sponges and buckets
- Tile spacers to match desired grout thickness (1/16" recommended)
- Grout (Use non-sanded grout if joint is less than 1/8")
- Grout float
- Pre-Sealant (DryTreat Stain Repella™ recommended)
- Tile Sealer (DryTreat Stain Proof™ recommended)
- Latex type gloves (recommended)

PRE-INSTALLATION

Prepare a perfectly level, clean, and dry surface (Make sure the surface is 3/4 inch below the desired floor height. Use transition strip otherwise).

NOTE: Make sure concrete is fully cured prior to installation to avoid evaporative moisture, which will create mineral deposits on tile. To ensure concrete is cured, take a small piece of plastic and tape to floor, taping all edges down thoroughly. Leave this plastic and tape overnight. If moisture appears under plastic used, that will indicate concrete is not cured and a moisture barrier will be required prior to installation.

INSTALLATION

1. Evenly apply thinset to cement floor using notched trowel, working in small sections.
2. Thoroughly wet backs of tiles with a sponge or dunk in bucket of clean water to remove any residue. Wet tiles to ensure even curing of thinset and reduce chances of thinset staining tile.
3. Cover or "butter" back of wet tile with thinset.
4. Set tiles, and checking with a level, press them into place with the palm of your hand to ensure all tiles are leveled across joints. DO NOT use a tool like a rubber hammer; this can cause fracturing.
5. Use tile spacers to achieve even grout lines.
6. After thinset has cured and tiles are completely dry apply one coat of DryTreat Stain Repella™ according to manufacturer recommendations [we recommend watching a DryTreat™ application video or looking for an accredited applier on their website].
 - Latex type gloves are recommended to avoid dirt and oil from hands getting on tile.
 - Immediately remove any thinset from visible surfaces of tiles to prevent potential staining.
 - When cutting tiles to space requirements, use a wet saw with a diamond blade.
 - If creating a layout with a pattern and border, start by centering pattern first, then work outwards.

GROUT INSTALLATION

1. Wait 24 hours after first application of DryTreat Stain Repella™ before grout installation
2. Ensure tiles are free of all debris
3. Apply grout with grout float working in small [4-6 tile] areas
 - We strongly recommend AGAINST the use of black or anthracite colored grout
4. **Clean off excess grout immediately. Do not let grout dry on tile surface or staining will occur**
5. Once installation is complete and excess grout is cleaned, let grout dry according to manufacturer recommendations
6. After grout has cured, apply two coats of DryTreat Stain Proof™ over both tile and grout following manufacturer recommendations. **It is extremely important tiles be completely clean of all dirt before sealing. If surface dirt remains prior to sealing tile it may permanently stain**

CARE AND MAINTENANCE

- Use a mild pH-neutral cleaner for ongoing cleaning and maintenance
- If stains occur, they can be removed by gently wet-sanding the problem area with 400 grit sandpaper. The sanded area will need to be resealed with DryTreat Stain Proof™ and resealed if wax was initially applied

DISCLAIMER

Casa Vita Bella provides these instructions as guidelines to the installation process. The final installation is the responsibility of the installer as conditions and application of projects may vary. Casa Vita Bella will NOT consider product or labor claims after material installation.

Tel: 888.900.2159 Fax: 866.305.4083 www.casavitabella.com

CASAVITABELLA

INSPIRED. INNOVATIVE. MODERN.

ARTISAN CEMENT TILE GUIA DE INSTALACION

MATERIAL Y EQUIPO

- Mortero de capa delgada (oscuro o claro dependiendo del color de la baldosa)
- Paleta llana dentada.
- Esponjas limpias y cubetas o baldes.
- Separadores de Baldosa o Azulejos que coincidan con el grosor del yeso o lechada deseado (2 mm o 1/16" de pulgada recomendado)
- Lechada o yeso (sin arena si el espacio entre las baldosas es menor a 3 mm (1/8" de pulgada)
- Espatula flotante de goma para yeso o lechada.
- Pre-Sellador (DryTreat Stain Repella™ recomendado)
- Sellador penetrante de pisos (DryTreat Stain Proof™ recomendo)
- Guantes de latex (recomendado)

PRE-INSTALACION

1. La superficie de instalacion debe estar perfectamente nivelada, limpia, y seca. (Asegurese de que la superficie esta a 1.9 cm o 3/4 de pulgada por debajo de la altura deseada para el piso, si es necesario use tiras de transición para pisos.

NOTE: Make sure concrete is fully cured prior to installation to avoid evaporative moisture, which will create mineral deposits on tile. To ensure concrete is cured, take a small piece of plastic and tape to floor, taping all edges down thoroughly. Leave this plastic and tape overnight. If moisture appears under plastic used, that will indicate concrete is not cured and a moisture barrier will be required prior to installation.

INSTALACION

1. Usando la llana dentada aplique uniformemente el mortero de capa delgada al suelo de cemento, trabajando en pequeñas secciones.
2. Pase una esponja mojada por la parte trasera de la baldosa o sumerja en una cubeta de agua limpia . Es importante que la baldosa este libre de residuos, limpia y humeda para garantizar que el mortero se adhiera correctamente y evitar manchas en la superficie del material.
3. En la parte trasera de cada baldosa mojada cubra o embarre con la mezcla de mortero.
4. Empiece a instalar las baldosas asegurandose que estan niveladas, ayudese con las palmas de sus manos, procure ejercer presion en los lugares que sean necesarios para asegurarse de que todos los azulejos se encuentran al mismo nivel . **NO TRATE DE UTILIZAR MARTILLOS DE HULE PARA NIVELAR.**
5. Use los separadores con el yeso o lechada para crear lineas que luzcan parejas.
6. Después de que el mortero se haya curado y los azulejos estén completamente secos, aplique una capa de DryTreat Stain Repella™ siguiendo las instrucciones del fabricante. [Le recomendamos ver un video de fuente confiable de como aplicar DryTreat]
 - Se recomienda usar guantes de látex para evitar que sucio y aceite de las manos se transfieran a las baldosas.
 - Remueva inmediatamente de la superficie cualquier resto visible de mezcla de mortero o revestimiento para evitar posibles manchas.
 - Si necesita cortar la baldosa para ajustar en ciertos espacios, utilice una sierra mojada con una cuchillo de diamante.
 - En caso de estar creando un patron especifico con borde, comience con el centro del patron y luego hacia los exteriores.

INSTALACION DEL YESO

1. Antes de instalar el yeso o lechada espere al menos 24 horas después de aplicar la primera capa de DryTreat Stain Repella™ .
2. Asegúrese que toda la baldosa esta libre de escombros y desechos.
3. Aplique el yeso con la espatula flotante trabajando en áreas pequeñas [4-6 Baldosas]
 - Reiteramos e insistimos en **NO USAR** yeso o lechada de color negro o gris oscuro.
4. **LIMPIE TODO EXCESO DE YESO INMEDIATO. NO DEJE QUE EL YESO SE SEQUE EN LA SUPERFICIE DE LA BALDOSA O TENDRA MANCHAS.**
5. Una vez que la instalación este finalizada y el exceso de yeso ha sido removido, deje que la lechada o yeso se seque de acuerdo a las recomendaciones del fabricante.
6. Cuando el yeso este curado y seco aplique dos capas de DryTreat Stain Proof™ sobre la baldosa y la lechada siguiendo las recomendaciones del fabricante.
7. **ANTES DE SELLAR ES EXTREMADAMENTE IMPORTANTE QUE LAS BALDOSAS ESTÁN COMPLETAMENTE LIMPIAS DE TODA LA SUCIEDAD. SI USTED SELLA LA SUPERFICIE AUN ESTANDO SUCIA QUEDARA MANCHADO PERMANENTEMENTE.**

CUIDADO Y MANTENIMIENTO

- Para la limpieza y el mantenimiento es recomendable usar un limpiador que sea suave y PH Balanceado.
- En caso de que ocurran manchas, éstas pueden ser removidas. En el area afectada con papel de lija suave y humedo de 400 granos lije hasta desaparecer. El área que lijo debe volver a sellarse con DryTreat Stain Proof™ y volver a encerar si se aplicó cera al inicio.

AVISO LEGAL

Casa Vita Bella proporciona estas instrucciones como pauta y orientacion en el proceso de instalación. La instalación final es responsabilidad del instalador debido a que las condiciones y aplicaciones de los proyectos pueden variar. Casa Vita Bella NO considerará reclamos del producto o trabajo después de que el material ha sido instalado.

Tel: (888) 900-2159

Fax: (866) 305-4083

www.casavitabella.com